
disconnected
dial
EOT
EOT1
EOT2
EOT3
EOT5
EOT4
transmission-role
heading
SOH
SOH2
DEOT1
DEOT
NAK
beforeBlock
nothing
STX
inBlock
STX1
NAK2
NAK3
STX3
RINT
RINT2
ETX
text
ETX1
DATA
RintNo
attention
DATA1
buffer
BlockNo
WACK
ACK
WACK1
wait
ENQ2
ACK2
ENQ
ENQ3
blockAbort
AckNo